

„Ergonomics of the workplace is the key for increasing of the productivity“.

This idea has created a new series of VarioLIFT tables.



VarioLIFT table with a tilting shelf

The work table VarioLIFT is designed for furnishing of all work places where is needed to change the table's worktop height in a short time or multiple times, for example in the shift-work, in control rooms or in supervisory workplaces.

#### How the VarioLIFT actually works

You are able to increase or decrease the height of the workspace in just a few seconds by simply pressing the button, so that you can freely change the position according to the present activity or when changing the seating and standing position. Ergonomic features of the table are complemented by the proven VarioLAB+ features. Thanks to this unique combination which other tables do not offer, we can create an optimal table set.

From a technical point of view, your new VarioLIFT table can have a device superstructure right on the table top or hanging over it, with the both fixed and tilting shelves, or a light ramp with LED lighting.

The basic characteristic feature of the VarioLIFT table is the free work space placed on a stable construction. The tables are designed as stand-alone tables.

The basic set consists of a metal base that carries the table top. The metal structure is provided with the powdered baked-on colour Comaxit and galvanized zinc. The worktop of the table is made of the resistant HPL or an antistatic 25 mm thick laminate with ergonomic front edge. The edges are made of 2 mm thick ABS plastic. The sizes of the worktop are given by a specific assembly in the widths of 1200, 1400, 1500, 1600, 1800 and 2000 mm.

They are designed for electronic production, repair or fine mechanics.

#### Main features:

- Electrically adjustable height
- Table widths of 1200, 1400, 1500, 1600, 1800 and 2000 mm
- Tabletop height from 670 to 1120 mm
- Shelf rack height up to 1200 mm
- Security features during set up
- Two separate drivers
- Modern ergonomic design
- Optional antistatic version
- Simple operation with buttons
- Full-value device superstructure
- Spacious work area
- Smooth height adjustability
- Wide choice of accessories and supplements
- Three different table widths
- Fixed and tilting shelves
- Durable and high quality materials
- Simple assembly



VarioLIFT table, detail of hanging device superstructure. The superstructure can also be made at the worktop version.



VarioLIFT table, detail of the electric height adjustment control panel. With using only one controller is possible to manage up to four drivers simultaneously. This function you can preferably use at connected work tables where is necessary to increase or decrease the work desks of more tables at the same time.